



Certified Environmental Radon Services

PO Box 727, Farmingdale, NJ 07727

Laboratory #13035
NJDEP MEB #94012

RADON TEST INFORMATION FORM

FAILURE TO COMPLETE ALL FIELDS MAY DELAY OR PROHIBIT ANALYSIS

OWNER/CLIENT: _____

ADDRESS: _____

STREET

CITY STATE ZIP

MUNICIPALITY

COUNTY

FOUNDATION TYPE: Basement / Crawlspace / Slab on Grade / Combination
(Circle all that Apply)

BUILDING TYPE: Residential / Non-Residential / School / Day Care / Day Care in Public School
(Circle One)

TEST PURPOSE: Real Estate / Screening / Post Mitigation /
(Circle One)

FLOOR LEVEL TESTED: Basement / First Floor / Second Floor / Other: _____

Closed house conditions? YES NO

Deploy License # _____ Retrieval License # _____

Deploy Tech _____ Retrieval Tech _____

Email Results To: _____ Mail To: _____

CAN/CRM ID#: _____ DUPLICATE ID# _____ BLANK ID #: _____

START DATE: _____ STOP DATE: _____
Month / Day / Year Month / Day / Year

START TIME: _____ AM / PM STOP TIME: _____ AM / PM

X _____
By Signing Above the Owner Waives Their Right to Confidentiality

THIS BOX FOR LAB USE ONLY

Date: _____ Result: _____ / _____ / _____ pCi/L

Lab Tech: _____

	WEIGHT			
Initial	_____	_____	_____	_____
Final	_____	_____	_____	_____



These placement instructions are for anybody placing a radon test.

CLOSED HOUSE CONDITIONS

The house should be under “Closed House” conditions for at a minimum of 12 hours prior to and for the duration the Radon test is exposed. This data sheet is for residences.

Choice of Location

To screen the residence for Radon exposure, select the lowest livable level of the building. This is usually the basement. Avoid bathrooms, kitchens, laundry rooms, closets, garages, and attics. Stay away from direct sun light, forced air registers, radiators, vents, doors, windows, fire-places, and basement sump pits. Place the canister a mini-mum of 3 feet from walls with openings to the outside, 1 foot below the ceiling, 4 inches from other objects, and 20 inches above the ground.

Radon Canister Instructions

- 1) Remove the plastic tape from the side of the canister. Open the canister by removing the metal lid and **SAVE THE LID AND TAPE** for resealing at the end of the test after the exposure is completed. Place the canister open face upon the testing site. (See “Choice of Location” for a guide on correct test placement) Enter the “Opened” date and time in the space provided on reverse side.
- 2) When the exposure is finished in 2-6 days, replace the metal lid on the canister and seal its perimeter where the seams meet using the tape provided. Enter the “Closed” date and time in the space provided on reverse side.
- 3) Immediately return sealed canister to:

**Certified Environmental Radon Services
PO BOX 727, Farmingdale, NJ 07727**

The canister must be exposed for 2-6 days. It is very important to observe these limits and return the canister to us within 7 days after exposure is completed and the canister is closed.

CRM Testing Instructions

- 1) Make sure key switch is in the “Enable” position.
- 2) Press and hold both buttons down until the LED illuminates to a solid yellow. When you release the buttons, it should flicker yellow.
- 3) Press and hold the “Clear” button down. The LED should turn off, then re-illuminate. At this point, the CRM is ready for use.
- 4) If you are not certain that the CRM memory is clear, follow procedure for preparing CRM for use.
- 5) Choose a location that complies with EPA/DEP placement protocols. If it is impossible to select a location that fully complies, chose the location that meets the protocols as close as possible.
- 6) Plug the CRM into a receptacle that is **NOT** tied into a light switch.
- 7) The CRM will go through the normal start up process and start recording data. Data should be recorded for a minimum of 24 hours. For greater accuracy, Certified recommends a minimum of 48 hours exposure time. The duration of the exposure can be up to 90 total time interval measurements
- 8) Turn the “Battery Backup” switch to on.
- 9) Turn the key switch from “Enable” to “Disable” and remove the key.
- 10) Turn the “Battery Backup” switch to off and unplug the CRM

Test results will not be issued unless data sheets are completely filled out. Missing data that would affect the test result will make the test INVALID.

**RADON TESTING IN PROGRESS
DO NOT TOUCH**